

We recommend all installations of this trigger be carried out by a competent gunsmith and with weapon unloaded and pointed in a safe direction. Failure to adhere to this warning can result in serious injury and/or death!

3MR trigger installation for AR15 and AR10



Prior to installing the 3MR, ensure all previous trigger components and selector have been removed. To remove the selector, uninstall the grip and remove the selector spring and detent. Use care to ensure you retain these parts. The 3MR will "drop in" as shown.



Allow the 3MR to drop in completely, making firm contact with the bottom of the receiver. Verify proper fitment by visually confirming the hammer and trigger pin holes align properly.



If you ordered an ambidextrous selector, choose your preferred paddle sizes and configuration. Fasten one paddle then install the selector assembly into the receiver. If you ordered a standard selector, verify the paddle is secure and install. When installing the selector, rotate the fore end of the trigger pack up to allow clearance.



Install the hammer and trigger pins from the right side of the receiver. Replace the selector detent and spring then reinstall the grip.



With the grip installed, function check the trigger. If you assemble the lower and upper receivers, exercise proper firearm safety procedures and refer to the rifle owners manual during this process. Rotate the selector into each mode and verify functionality, including the assisted reset in 3rd mode, and ensure the trigger will not fire while on safe.